



ROTATE COUNTER CLOCKWISE
REMOVE CLAMP AND DISCARD.



SCREW NEW SUPPLIED BLACK
CLAMP ONTO END OF TUBE
THAT OLD CLAMP WAS REMOVED
FROM.




COMPRESSION
NUT

SUPPORT ROD

WALL
BRACKET

DETERMINE CORRECT LENGTH OF SUPPORT
ROD FROM WALL TO RISER PIPE. REMOVE
SUPPORT ROD BY UNSCREWING THE
COMPRESSION NUT. CUT ROD AT NON-THREADED
END, TO APPROXIMATE SIZE NEEDED.



FLEX SPRAYER
HOSE

RISER PIPE

MOUNT WALL BRACKET WHERE
AS THE TOP OF THE BLACK RETAINER
IS JUST BELOW THE SEAM WHERE
THE FLEX SPRAYER HOSE SCREWS
ONTO THE RISER PIPE.

TOP OF HOOK COLLAR TO BE
A MINIMUM OF 9" BELOW THE
BOTTOM OF THE WALL MOUNT
BLACK RETAINER.